

HOMEOWNERS INSTRUCTIONS

Your gate has been equipped with a DoorKing Telephone Entry System. Please read the following instructions to familiarize yourself with the operation of this system. If you have any questions, please contact Sharon Smith.

ESTABLISHING COMMUNICATION

Your telephone number has been programmed into the telephone entry system, and has been assigned a three digit code. If you have guests coming to visit you, be sure they know your code before arriving. If the visitor knows your directory code, he can simply enter this code on the keypad of the telephone entry system to establish communication. When a visitor comes to see you and does not know your code, he will have to call from an outside phone, either at Sierra Village or at Long Barn.

GRANTING OR DENYING ACCESS

If you wish to allow your visitor entry, simply press "*9" on your touch tone telephone. You may have to press twice. The entry system will put a tone in your telephone handset indication that the gate has been opened, and will hang up. If you have a rotary telephone, dial the number 9. When you hear the tone indication that the gate is opened, hang up. You may have to dial 9 twice on some phones.

If you do not want to grant the visitor access, tell him so and then hang up.

If you are on the telephone when a visitor tries to contact you, they will receive a busy signal at the telephone entry system.

Your three digit code is _____

NAME _____

Sent first class August 1996